

1 DISCONNECT AIR SUPPLY BEFORE STARTING!!!

6

INSTALL O-RING
ONTO TARGET

2

REMOVE 10 SCREWS
WITH A 5/64 HEX KEY.
TAKE COVER OFF MACHINE.

3

REMOVE TARGET LINE
FROM VALVE.

4

PLUG AUXILIARY AIRLINE INTO VALVE.
(4 INCH LINE ALREADY INSIDE MACHINE)

5

INSTALL FITTING AND
AIRLINE TO FOOT
SWITCH.

